

The bulk of MACH3 and the Hardware has to do with Inputs and Outputs (I/O). In the BladeRunner AIO system I/O takes several forms. Ultimately an INPUT is a signal coming INTO MACH3 from an external source as a logic level (either Active High or Active Low) MACH is setup to "watch" certain Ports and Pins (input points) and then using a term called "mapping" it assigns an INPUT to an ACTION. The BladeRunner is unique in that it has double the number of normal inputs to a single Parallel (printer/LPT) port so you have more than the normal 5 inputs to work with. This is essential when using the THC function in MACH because it alone needs 3 dedicated inputs.

**It is important to understand how the input Port Expansion works and how the mappings are used.**

The UBOB III is the hardware I/O part of the BladeRunner. It takes outside inputs from the Table I/O card to sense physical switches and sets up the "sharing" of the inputs. There are two PORTS defined in the setup. PORT1 and PORT8. PORT 8 is the shared port to PORT1. The physical inputs are individual and each one is opto-isolated and noise filtered. The circuit in the UBOB III takes all of the individual inputs and puts them on TWO BANKS of signals.....4 on each bank (E-STOP is not shared). A special pulse is sent from MACH to tell the hardware which BANK to read. This happens thousands of times per second in a process called "multiplexing". MACH alternately reads all of the inputs from BANK A (PORT 1) and then from BANK B (PORT 8). It is an effective way to increase the number of input signals without having to add more physical inputs at the computer.

**There are two things to keep in mind:**

**The shared inputs do not work when MACH is in RESET** because all outputs are off and that includes the special pulse from MACH to switch back and forth between the two BANKS of inputs.

**The shared input process is controlled through a special DRIVER** (plug-in) for the UBOBIII. It has to be installed and enabled and set correctly for the shared inputs to work.  
(versions of MACH3 before 3.41.020 DO NOT SUPPORT SHARED INPUTS even if the UBOBIII driver is loaded. UBOB driver is ccc\_UBOB.dll. **It is added during an auto-install from the CD or the BladeRunnerAIO-UBOB3-Install file.**

The DTHC critical signals of THC ON (Arc OK), THC UP and THC DOWN and the Z home for the IHS (Initial Height Sensing aka "Touch-off") are REQUIRED for a Plasma setup. Other inputs are not required but highly recommended to help in the cut process.

When you load the BladeRunnerAIO-UBOB3-Install file earlier in this manual it loads the right Drivers (plug-ins) enables them and sets their parameters. It also provides a default configuration for all of the INPUTS and OUTPUTS that are common on the BladeRunner. The following screens show what the default settings will look like. There may be differences in settings for inputs NOT ENABLED. Do not worry. A disabled input is ignored by MACH3. Only the pins that are enabled count.

## THE DEFAULT SETUP

- 1, XYZ&A Homes are enabled and set to the correct port/pin pairs
2. All LIMITS are disabled (see setting up LIMITS for details)
- 3 The THC INPUTS are all enabled and setup...even on a Router Profile since those inputs can be re-purposed and used for other functions if desired.
4. The E-STOP cannot be disabled and the Active Low setting is critical (RED X default)

## SETTING and TESTING INPUTS - HOMES

Each axis as a ++ and -- which are the FAR and NEAR LIMITS. Each axis has a HOME  
Each axis has an Enabled Column. **Do not use Emulated ON** (Red X for normal setups)

Engine Configuration... Ports & Pins

Port Setup and Axis Selection | Motor Outputs | **Input Signals** | Output Signals | Encoder/MPG's | Spindle Setup | Mill Options

Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
X ++		8	11			0
X --		8	11			0
X Home		1	11			0
Y ++		0	0			0
Y --		0	0			0
Y Home		1	12			0
Z ++		0	0			0
Z --		0	10			0
Z Home		1	13			0
A ++		0	0			0
A --		0	0			0

Pins 10-13 and 15 are inputs. Only these 5 pin numbers may be used on this screen

**DO NOT USE THIS BUTTON!** Automated Setup of Inputs

OK Cancel Apply

The BladeRunner is unique in that it has two input PORTS (1 & 8). The pins are "shared" so that PORT 1 Pin 11 is shared with PORT 8 PIN 11. That offers double the normal inputs

Z Home		1	13			0
A ++		0	0			0
A --		0	0			0
A Home		1	15			0

Note: A home is enabled by default. This may need to be changed if you do not software slave A to another axis with a Home. See the setup of Homes & Limits section for details

Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
Input #2		0	0			0
Input #3		0	0			0
Input #4		0	0			0
Probe		0	0			80
Index		0	0			0
Limit Ovrd		0	0			0
EStop		1	10			0
THC On		8	12			0
THC Up		8	13			0
THC Down		8	15			0
QEM Trin #1		0	0			0

Pins 10-13 and 15 are inputs. Only these 5 pin numbers may be used on this screen

E-Stop Cannot be disabled. The Active Low value is important. Note THC related signals are on PORT 8. THC ON is the same as ARC OK.

### THE CHARGE PUMP

The Charge Pump (CP) is an important safety signal in MACH and used by the BladeRunner. It is a 'Keep Alive' signal that is a waveform (approx 12 KHZ) and is generated by MACH and controlled by MACH and the CandCNC drivers. If for any reason the power to the control system is turned on before the PC is powered up it is possible that as the PC "boots" the parallel port can have signal changes (during POST) that would might cause an output to go active.

Stepper motors require very specific signals to move making them inherently immune to random port signals. The circuits in the BladeRunner do not allow any signal to pass to any of the drives unless MACH is fully started and is functional and the operator has brought the system out of reset. NO CP, NO OUTPUTS!

### HOW IT WORKS:

MACH is programmed to turn on the CP only when MACH is loaded **and has control of the PC and the parallel port and MACH is out of RESET.** While MACH controls the output signals through internal logic there are hardware functions that act as a second level of safety. In the UBOB III based system the CP signal **MUST** be present (not just a logic level) on the CP line from the PC or the internal buffers will be disabled. No outputs will function. **Without CP no Step signal will be sent to any motor drive (No MOTION). Without CP no relay will fire.**

If you start MACH and the BladeRunner and you get no motion the first thing is to check the CP LED on the side of the BladeRunner. It detects and turns on the buffer circuits in the BladeRunner.

## TABLE I/O CARD LOCATION


### CHECKING INPUT SIGNALS:

The following sections detail how to use the hardware interface to use Inputs and Outputs. Please review the section on the physical location of the internal cards and then the section on the Table I/O card (where Homes and Limits and other Inputs are connected). There are sections on using the E-STOP (either software or hardware or both) Setting up HOMES and testing and optional LIMITS. Even if you do not plan to use the XY or A homes it is important to at least test each input.

### TABLE I/O MODULE LOCATION INSIDE BLADERUNNER AIO ESPII CASE

To access Inputs turn off power and remove front cover. Locate Table I/O Card and use detailed pages in this section to make INPUT connections

### INSIDE TOP VIEW



## BLADERUNNER UBOB MODULE DETAILS

Setting up HOMES.

Homes are used for establishing a known POSITION, Most often to define the TABLE ZERO locations and be able to return to the same fixed spot. Much like the address on your house versus the location of your RV at any given time. If you establish a TABLE 0 and do all of your cutting in reference to the TABLE ZERO then you can always re-establish your cut at anytime even after a power failure and E-STOP event that can cause the loss of position.

### TESTING HOMES at the TABLE I/O.


If you have not yet mounted or wired your HOME switches yet, it is easy to test to make sure of their operation:

1. **UNPLUG THE AUXILIARY AC CORD THAT PROVIDES POWER FOR THE AC SOCKETS BEFORE YOU RUN ANY TESTS!** You will need to power up the BladeRunner and the DC supply to run the INPUT tests but there is no AC high voltage in the top of the unit **UNLESS YOU HAVE THE AUX AC CORD PLUGGED IN.**
2. **Open the BladeRunner up** (remove the cover and place it gently off to one side leaving the cables to the Front Panel plugged in. Expose the TABLE I/O in the top of the case as shown in the illustration on page\_73 Note the input terminal pairs are side by side in two rows.
3. **Power up the BladeRunner AIO** with and turn on the DC (Front Panel). You do not need the motors plugged in, but if they are it is okay. MACH will not come out of RESET if the DC power is off. Inputs do not work right if MACH is in RESET
4. **Make sure MACH3 is loaded and the BladeRunner Profile is selected.** Open the DIAGNOSTICS PAGE for the test
5. **To test the inputs** use a small screwdriver or metal object to short across a pair of inputs. Start with X Home and go down through A home.
6. Note on the TABLE I/O Card **there are small LED's next to each pair.** When you short across a pair you should see the associated LED turn on. That indicates the circuit is complete between the Input on the Table I/O and the UBOBIII. It also confirms the 25 pin cable is working.

# SETTING and TESTING INPUTS - HOMES


MAKE SURE THE AUX AC INPUT CORD IS DISCONNECTED FROM THE WALL SOCKET BEFORE YOU RUN ANY TESTS

DANGER ZONE  
WHEN AUX AC  
CORD IS  
PLUGGED IN




## INPUTS

TO TEST:  
SHORT  
ACROSS  
INPUT PAIRS



Flashing INPUT  
on RAW PORT  
INPUT BITS



Example of testing X HOME input and indications on the DIAGNOSTICS SCREEN. Test each input at a time and match up the INPUT STATUS. The RAW PORT BITS shows the signal AT THE PORT 1 input on the PC as MACH sees it. NOTE: You cannot test the LIMIT input. The AUX 0 is NOT an input for the BladeRunner.

## Checking the INPUTS


RAW PORT INPUT BITS  
BIT 4 = A home/THC DOWN  
BIT 5 = Z home/THC UP  
BIT 6 = Y home/ARC OKAY  
BIT 7 = E-STOP(EPO)  
BIT 8 = X home/LIMITS

## NORMAL INDICATIONS

With PORT1 unplugged from BladeRunner: All Bits (4 - 8) should be ON STEADY  
When MACH is out of reset then you should see the RAW PORT BITS SHOWN ABOVE. **Flashing inputs** indicate activity on that input (E-STOP MUST BE OFF - STEADY (dark))



**Home Switch Connections:** At least one Home (Z) is required if you are using the BladeRunner Dragon-Cut for plasma tables. It is recommended you mount and connect up HOMES for the X & Y but it is not required.



## EXAMPLE of HOME SWITCH

MicroSwitch Type switch with roller lever actuator. Switch has .250 quik connects and a NO and NC set of contacts. Mounting in this case is drilled and tapped AL block with High Strength 3M double-sided tape holding it to the table frame. Switch trips on bottom of gantry frame but allows it to roll past if needed.

Mount your HOME Switches so they define the X and Y zeros on your table. Mount some clips or brackets (stops) on the cutting surface or edges to let you index a sheet of material in relation to the table zero. Even if the STOPS are not exactly at table zero you can deal with the offsets in the CAM layout. **Having alignment stops on your table let you accurately remove then re-load a piece of material. Having a defined table 0, 0 that can be referenced to makes the recovery of a loss of absolute position easy** to recover from. We have provided enough inputs to allow for up to 4 Homes.


The Z home setup is covered on the next page and depends on the type Floating Torch Holder you are using.

The BladeRunner AIO enclosure is furnished with 2 access holes for routing switch wires into the box for connection to the tabs on the TABLE I/O card. The holes are filled with two rubber knock-out plugs that are easily removed. HOME switch wires carry very small amounts of current (< 15ma) and low voltage (3 -5 volts DC) so the wire size is not critical. It is recommended it be stranded for flexibility on any moving part of the table and for longer runs twisted pair(s) are recommended. Wire from 24Ga to 18Ga works best. The smaller the conductor the more wire pairs will fit through the access holes. Use the correct sized Crimp-On connector for the size wire you use.



Switch Wire Access  
Plugs on End of  
BladeRunner AIO


## Z AXIS "Touch Off" SWITCH Z HOME



Example of a Z with the Floating Torch Holder for doing the IHS for Plasma cutting.

### WHAT IS A FLOATING TORCH HOLDER and WHY DO I NEED ONE?

The Floating Torch holder is a torch holder mounted on a separate slide from the Z axis and allows the torch to move UP and DOWN independent of the Z motion. In operation it uses the end of the torch (torch tip) as a "Probe" to find the Top-of-Material. Because metal tends to warp and the slats may not be perfectly level, the Z zero changes (top of the material) as you move around the table surface. The DTHCII will track the rise and fall of the material as it cuts to hold a constant arc gap, BUT the absolute value of Z as displayed by the Z DRO is based on the LAST REFERENCE DONE. (Where it started) Each pierce needs to be done at exactly the right height above the material so a method of **Initial Height Sensing** (IHS) is needed. The Floating Torch holder lets the Torch be the sensing probe for the IHS. It is a mechanical way to do the probe and is more reliable than ohmic or capacitive sensing. Using a Z homing sequence generated by the G-Code (from SheetCAM) the Z is lowered until the tip of the torch touches the metal and the floating mount allows the torch to be pushed UP and that trips the switch.



Z AXIS FLOATING HEAD SWITCH. Close up of switch connections. Use Normally Open Pair.

(Precision Plasma HD Gantry and Z)  
CONNECTED TO Z HOME in BLADERUNNER on the TABLE I/O




Using an Optional Salve Side Home Switch;

It is advantageous to use a HOME on the slaved axis (in this case A). There is an input for an A HOME. If you set your inputs to have an A HOME in INPUT SIGNALS then slave the A axis the gantry will move towards the switches and stop the motor on the first one to make contact. The other axis will continue to run until it contacts its switch. If the two sides have gotten out of sync the XY REF will let the gantry "Auto-square" itself.


If you make the bracket on one side or the other adjustable you can fine tune the position and square the gantry with the table.

If you elect NOT to use a slave axis HOME (in case you need the input for something else). You must still enable A home in the MACH Profile but map the A home to the same Port and PIN as the Master Home (Y in this example)



Typical rectangular table setup

4 motor setup (dual drive on the gantry)



If you stand here to run the machine then 0, 0 is lower left corner from your location. X is cross axis (short axis)

## SETTING HOME SWITCH "SEEK" DIRECTION.

Each HOME Switch in the system has an associated set of parameters to define how it is used.

To access the Configuration Menu open the CONFIG/Homing&Limits window shown below. Most of the defaults will be correct. The HOME NEG setting tells MACH which way to move to find a home switch. After you setup your home switches you should test each one and setup the seek direction.

1. Make sure the HOME switch shows up in the Diagnostics Window when you manually activate the switch. On the Z home for a plasma setup using the floating Torch holder, manually raise the torch by hand and test the switch.
2. Do one axis at a time. In the Program Run and the Diagnostics Tab you will find a REF button next to each axis DRO. Move (jog) each axis out several inches away from it's home switch. Click the REF button on the X axis and if it starts to move AWAY from the HOME Switch, stop the motion and open the Home & Limits window and click the Home NEG indicator for that axis. Each time you click it will change the setting from a Green Check to a RED X and back. Set it to the opposite value and click OK. Re-Test the REF on the axis you changed and make sure it moves to it's Home Switch.
3. Test and set each axis Home that you have

When Homing, the Z axis on a Plasma setup should move down to the material. It will move until it trips the Z home switch then stop, IT WILL NOT AUTOMATICALLY PICK UP THE Z above the material.

Motor Home/SoftLimits

Entries are in setup units.

Axis	Reversed	Soft Max	Soft Min	Slow Zone	Home Off.	Home Neg	Auto Zero	Speed %
X		60.00	0.00	1.00	0.0000			20
Y		99.00	0.00	1.00	0.0000			20
Z		6.00	0.00	0.50	0.0000			20
A		99.00	0.00	1.00	0.0000			20
B		100.00	-100.00	1.00	0.0000			20
C		100.00	-100.00	1.00	0.0000			20

G28 home location coordinates

X 0

A 0

Y 0

B 0

Z 0


C 0

OK


## Home and limit switch hook ups

Typical connections for Homes and Limits

All of the inputs are opto isolated and map to a specific pin on the parallel port(s). In reality you can use any input for any signal. Inputs are not fast enough for Encoder feedback faster than a few pulses per second. The inputs use a "floating" ground (+12 return). If you need more inputs than the 8 (9 with EPO) then a PORT 2 card can be hooked to the UBOB and the added Aux and



**QUAD RELAY HEADER**  
is for an optional quad relay card  
and adds 4 more relays to the outputs.



The X Home should light up when you manually activate X Home switch. It should be off when the switch is not active. If it is reversed (i.e. goes OFF when you activate the switch but stays on otherwise) you will need to reverse the polarity of the switch in Ports & Pins/ Input Signals. We recommend using normally open (NO) contacts on Homes and Normally Closed (NC) contacts on the far limits (if used).

The far limits are wired in series external to the Table I/O card and it is setup so breaking the string at any point activates a hard limit. The hard limits are safety switches located at points on the table to prevent the machine from going past the table travel limits. You can have far limits (opposite the 0,0 location of the table) AND near limits (at points where the machine would crash on the other side of the Home switches. Limits are optional and on stepper based systems you could elect to have just hard stops since the motors can be stalled without damage.

#### **A NOTE ABOUT LIMITS on the BladeRunner:**

A stepper motor/driver is a "torque limited system" meaning that the drives limit the amount of torque a stepper motor can apply to a load. It does that by limiting the current on each pulse. While most AC and DC motors will quickly exceed their ratings if presented with a large overload, the stepper just stalls (starts slipping) and "loses steps". Because if this they are safe from overload and will simply stop turning. Simple mechanical stops on an axis will keep motors from running to far and no damage to motor or drive is inflicted. It sounds bad because the motor vibrates as it attempts to turn but no harm is done. The motor will not overheat and the electronics will not see it as an overload unless all 4 motors are stalled at the same time. LIMITS are more for decoration than function on a stepper system. Some users like to have them. If that describes you then by all means install and set them up...you will feel much better!

## SPECIAL MANUAL JOG INPUT For Oxy-Fuel Cutting

SPECIAL SECTION: Hooking up a remote control for doing Oxy-Fuel cutting. Disregard this section if you do not have an oxy-fuel setup on you table. IF YOU DO WANT TO SETUP AN OXY\_FUEL SYSTEM PLEASE NOTE THE FOLLOWING:

1. Setup and copy your working Plasma Profile using the MACH LOADER covered in Page 34 of this manual.
2. Make the changes listed on the next pages to THAT NEW PROFILE.
3. You can control the Z UP and DOWN manually during flame cutting using either a set of switches OR the PC keyboard but not BOTH.
4. There may be some reconfiguration of outputs needed for oxy=fuel if you want automated control of the Oxygen valve and/or an automatic striker.
5. The THC cannot sense the height of the tip since there is no cutting volts or current to read. Typically oxy-fuel is done on thicker material and at much slower feedrates than plasma so manual height operation is possible.





## SPECIAL MANUAL JOG INPUT For Oxy-Fuel Cutting

**Engine Configuration... Ports & Pins**

Port Setup and Axis Selection | Motor Outputs | Input Signals | Output Signals | Encoder/MPG's | Spindle Setup | Mill Options

**Z - Inhibit**  
☐ Z - Inhibit On  
 Max Depth  Units  
☐ Persistent

**Compensation G41,G42**  
☐ Advanced Compensation Analysis

**Digitizing**  
☐ 4 Axis Point Clouds  
☐ Add Axis Letters to Coordinates

**Loop Control**  
☐ Allow Servo Hold on Input#1  
 Max CL Closed Loop Emulation

**THC Options**  
☒ Allow THC UP/DOWN Control even if not in THC Mode.  
☐ G28.1 No Initial Move.  
☐ Set OUTPUT5 when in THC

**General Options**  
☐ Homed true when no home swithes  
 G73 Pullback

OK Cancel Apply

If you want to use the manual UP and DoWN inputs on the Table I/O card for controlling the Z while code is running you can use one of the swtich setups on the previous page into inputs. You must then open the COFIG in MACH and select PORTS 7 PINS and the MILL OPTIONS TAB as shown. Check the "Allow THC UP/DOWN Control even if not in THC Mode" Checkbox and then APPLY button. This sets up MACH so it will listen to the UP and DOWN commands even when the THC Button is OFF in MACH. Also remember that the UP and DOWN inputs on the Table I/O card are in parallel with the UP and DOWN signals from the DTHC so MACH will LISTEN TO EITHER. The manual UP and DOWN is not normally used with the DTHC and the THC Button enabled. **You CAN manually control the plasma height if you turn off the THC button and have the above box checked but it is not recommended. The speed at which plasma normally cuts and the small arc gaps involved makes the reaction time too slow for manual Z spacing**

To do the same thing using the keyboard you must setup the INPUT Pins in MACH so THC UP and THC DOWN use EMULATED enabled (green check). You can then click on the HOT KEY for each and use the Set Hotkey to select two keyboard keys. Do not use keys assigned to any other function! While you can use both hardware swtiches and the keyboard hot keys it could get confusing. We present both as options but recommend you use one of the other

**Engine Configuration... Ports & Pins**

Port Setup and Axis Selection | Motor Outputs | Input Signals | Output Signals | Encoder/MPG's | Spindle Setup | Mill Options

Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
Probe		0	0			80
Index		0	0			0
Limit Ovrd		0	0			0
EStop		1	10			0
THC On		8	12			79
THC Up		8	13			85
THC Down		8	15			68
OEM Trig #1		2	3			
OEM Trig #2		2	4			
OEM Trig #3		2	5			
OEM Trin #4		n	n			

Pins 10-13 and 15 are inputs. Only these 5 pin numbers may be used

**SetHotKey**

Press any Key

BladeRunner  
Hardware

OR

UP

ON-OFF-ON  
Center off.

NC


cc

NC



# USING OPTICAL SENSORS FOR INPUTS

**WARNING** Do not attempt this option unless you can read and understand the schematic and have the wiring skills to make the connections and test equipment to troubleshoot the setup.. We offer this page as an **EXAMPLE** as to how to wire in other types of sensors. It does not represent components or products we sell or provide in the BladeRunner. We have been asked in the past on how to do this and this page is the documentation of that request. .Please do



Normally a NO switch is connected across T12 and T13 terminals (X-Home) and closing the switch turns on D4 through the cable to ISO1 on the UBOB. Since there are two LED's in series (equal to 4 diodes) current from the 24V side will not flow backwards through the LED's and damage anything. Reverse breakdown of LED is > than 24VDC.

R3 Values	Aux volts
330	5 VDC
680	10 VDC
820	12 VDC
1.5K	24 VDC

AUX 5 to 24VDC Supply to match Opto switch. Do not Ground neg side of power supply to external ground or chassis. Negative side needs to connect to input circuit common (Floating Ground on the Table I/O card ONLY)

**CANDCNC**

OPB9171Z Slot Opto  
Out goes low when light path is interrupted. Low signal turns on input

In the BladeRunner system there are two forms of E-STOP:

Software (MACH3 based) E-STOP  
Hardware (ESPII / UACM Card) E-STOP

### SOFTWARE E-STOP

In MACH there is a mandatory input for E-STOP. It is implemented as a normally closed input (must be held low to come out of RESET). That input is assigned in the BladeRunner AIO to input pin 10. With nothing attached to that pin it is pulled high by the parallel port. IF MACH is in RESET, all outputs are disabled and no inputs are acted on (ignored).


There is a general misunderstanding about software E-stop and if it is safe if the motors are still under power. The answer lays in the fact that a stepper based system like the BladeRunner HAS TO HAVE PRECISE TIMED SIGNALS to special drivers to initiate motion. It cannot simply "run away". It is virtually impossible to make a stepper motor turn without the operating software (MACH) and the electronics providing a valid pulse stream. In any failure scenario of the hardware (drive malfunction, shorted/open signals, disconnected wires, loss of power, etc) motor rotation is not possible. Since the software MUST be in control to issue pulses and the Charge Pump will turn off if the software is frozen, in a loop, or malfunctioning, putting the software into RESET for any reason will stop motion. It is actually harder to get motion when you SHOULD have it than to have a stopped system. One of the added benefits to a stepper based control is IF IT DOES NOT HAVE VALID STEP COMMANDS IT LOCKS THE MOTORS if power is still on the drives. Any consequence of applying DC or a short to any motor winding will cease rotation and typically lock the motor. The only argument is that the input device for E-STOP might fail, but that is no more likely than a failure of a HARDWARE based e-stop. So a failed drive will not cause a motor to Run Away. A failed computer or communications interface will not result in random or uncontrolled motion. Coupled with the Charge Pump (see section on the Charge Pump function) the probability of any motion more than .050 inches is about the same as a computer attached to a printer and no keyboard activity (no user) firing up and printing a perfect copy of the Magna Carta from random noise.

Since it REQUIRES concise control from the software to create motion the software can effectively control it going into RESET and E-STOP

The user can willfully disable Software E-STOP by setting the E-STOP input to read the wrong polarity and render the E-STOP disabled but a hardware E-stop can be disabled as well.


## E-STOP and Safety Shutdown SOFTWARE E-STOP

Implementing a SOFTWARE (ONLY) E-STOP. The BladeRunner AIO when properly setup will be put into RESET if the E-STOP (EPO) string is broken.



System is ACTIVE ON. All connections, voltages and components MUST be intact and working OR the system will Software E-STOP. Anytime power is off MACH cannot come out of reset. Jumper at EPO can be a string of “N...” switches (NC in series) that can be wired at any point on the equipment. any switch or connection in the string that open will trigger an E-stop. Once closed condition is restored the operator must initiate a RESET to bring the system back out of Software E-Stop

DANGER ZONE  
WHEN AUX AC  
CORD IS  
PLUGGED IN



INPUTS

EPO MUST BE JUMPED  
(Closed). Jumper can be replaced  
by one or more Normally Closed  
Switches (in series) for Software E-  
STOP





## E-STOP and Safety Shutdown HARDWARE E-STOP

**HARDWARE E-STOP.** As an option there are connections provided for a Normally Closed Hardware E-stop that removes current flow from the Control relay. The Control relay is a small electro-mechanical DPDT relay that DIRECTLY provides power to the Main Safety Relay (AC INPUT RELAY). This is a direct shutoff with no semiconductor failure points. When the HARDWARE E-STOP is tripped the DC power is removed from the motors, dynamic braking is applied (Load Dump), a software e-stop is sent via the second set of realy contacts on the Control Relay, and the processor that controls all of the power monitor and functions is signaled. As long as the Hardware E-STOP is OPEN (tripped) than the AC is removed from the main power supply. Barring failure of *both* the processor and the control software, there is no possibility of motion from the system even if the Hardware E-STOP is pulled out of tripped condition


**USE Dotted wiring for single switch. You can wire multiple switches in series as long as they all are Normally Closed when inactive. Pushing any switch in the string will OPEN**

**Switch must be Normally Closed and OPEN when pushed (or pulled on some types). If switch is mounted more than 6 ft from Front Panel card use twisted pair wire. 24 to 20 ga wire is okay.**

**REMOTE SWITCHES NOT INCLUDED**



**J4 MODE JUMPER ON UACM FRONT PANEL CARD**



# SETUP & TESTING OUTPUTS

G

BladeRunner  
Hardware

The BladeRunner AIO uses a unique method to get expanded outputs from just one Parallel Port. Using the CandCNC UBOB III technology the outputs are mapped to a "Virtual Port" (PORT 4). The status of each of those outputs is held in MACH on the PORT. The ccc\_comm plug-in then uses three of the parallel port pins (1, 14 and 16) to send the data to the UBOB III card. The data has 8 bits and that represents the status of 8 individual outputs. The data is read and updated many times per second so any change in the MACH settings get refreshed in the hardware quickly. Unlike most MACH Breakout Boards (BoB's) the UBOB III can control up to 8 independant relay outputs.

Port Setup and Axis Selection	Motor Outputs	Input Signals	Output Signals	Encoder/MPG's	Spindle Setup	Mill Options
Signal	Enabled	Port #	Pin Number	Active Low		
Output #1		4	8			
Output #2		4	3			
Output #3		4	4			
Output #4		4	2			
Output #5		4	5			
Output #6		4	1			
Charge Pump		1	17			
Charge Pump2		1	17			
Current Hi/Low		0	0			
Output #7		4	6			
Output #8		4	7			

Pins 2 - 9 , 1, 14, 16, and 17 are output pins. No other pin numbers should be used.


## DO NOT MAKE CHANGES TO THE Charge Pump SETTINGS

Signal	Enabled	Port #	Pin Number	Active Low
Output #18		1	1	
Output #19		1	14	
Output #20		1	16	


Pins 2 - 9 , 1, 14, 16, and 17 are output pins. No other pin numbers should be used.

Note: the Output SIGNAL name above is mapped to a PORT/PIN pair and that defines which physical device is activated by the UBOB output section. While there are 8 signals two of them (pin 7 and Pin 8 ) are used with the DTHC internally. Pin 8 goes though the DTHC module and fires the Torch Relay (on a plasma setup) in the THC SENSOR PWM module.

OutPut Status					
	Digitize		Output 2		Output 3
	Output 1		Output 5		Output 6
	Output 4				



# BladeRunner Hardware







# 

### 

Once you have established that you are getting proper inputs (see previous page) then you can test the outputs. With the BladeRunner connected and powered up and with the DC power on (Front panel White Button pushed and GREEN Led is ON) then open the Diagnostic tab



Bring MACH out of RESET (Indicator on steady GREEN)  
If you cannot come out of RESET see previous page for ESTOP input being OFF




Charge Pump LED (Yellow)

As soon as MACH is out of RESET the CP (Charge Pump) LED on the side of the Bladerunner should come on steady



No CP will inhibit ALL outputs including Motor motion signals. Nothing will turn on or move. Lack of CP shows the parallel port is not working or at the wrong port address in MACH. You can also get no CP if you are not running the correct profile or the ccc\_Ubob and ccc\_comm plug-in's are not active.



Once you have the CP on you can trip an output and it will start to *flash* in the OUTPUT STATUS. Plasma systems will have 3 outputs (Torch is output1). Routers only have two outputs.

If you want to test the physical outputs on a Blade runner plug an AC device (lamp, fan, etc) into the A or B outlet on the end and toggle Output 2 or 3 to turn it on.